

## 1600 "JR" Prism Assembly

ITEM NO.	DESCRIPTION	P/N
1	HOLDER	1600-1602-A
2	SCREW, SOCKETHEAD, 2-56 x 1/4	1600-0044
3	BUBBLE LEVEL	1600-0028
4	FRICTION PIN	1600-1605
5	YOKE	1600-1601
6	PLUMB POINT	1600-1606-A
7	SPACER SCREW	1600-1615-A
8	PLUMB LINE HOLDER	1600-1614-A
9	LENSE COVER	1600-1616
10	PRISM ASSY, 1" (25.4mm)	1610
11	STORAGE BAG (not shown)	1600-1685

